



# Robotic Arm Platform

Team Victory Lap

Erin Brennan  
Alec Fenichel  
Eric Hom  
Josh Lieberman  
Shaun Orr

# Model Breakdown


Part 1: Trusses

Part 2: Base Platform

Part 2: Lift Mechanism

Part 4: Assembly Method

# Overhauled Truss Design





## Truss details:



- Accurate to Prolyte Group's XU30D Truss design
- Aluminum 6061
- 4 Meters in length (using 3 pieces for total assembly)
- Link:  
<https://www.prolyte.com/en/products>

# Trusses

- Trusses at 45 degrees
- Inside beams are 2m apart in an equilateral triangle
- Plates to connect the bases




# Platform



# Arm Plate

Max Displacement: 0.0387 mm



Max Von Mises: 63 MPa





Plate Thickness:  $\frac{1}{2}$ " (12.7 mm)

Yield strength of steel: 250 MPa

# Lift Mechanism

- Winch - 750 lb payload
- Snatch Block Pulley



Shown  
Open

# Assembly Methods



Options:

1. Use a truss lifting device

Negative: Only feasible if tank if diameter is larger than height

Positive: Quick assembly, commercial sourcing option

2. Use our platform (like a crane)





# Next Steps: FEA

- Static Analysis:
  - Test for rigidity when arm is static ( $F = 375.7 \text{ N}$ )
    - Test when oriented straight up
  - Test for rigidity when arm is static ( $M = 209.75 \text{ N m}$ )
    - Test when oriented straight forward
    - Test when oriented straight backward
    - Test when oriented straight left/right (symmetry)
  - Test for rigidity when arm is moving ( $M = 294.21 \text{ N m}$ )
    - Test when a clockwise and a counterclockwise moment is applied on each axis (x, y, z)
- Vibration Analysis
  - Determine natural frequency and modes